

application guide for installation

* NOTE: The temperature in your application room must be at least 50°F/10°C
Puncture any small bubbles with a sharp needle, then press out any trapped air with your fingers. Please allow at least 4-6hrs for adhesion curing process. Run your fingers along all edges to make sure its sealed.



- Supplies Needed:
- Squeegee (supplied)
 - Sharp Exacto Knife/razor scraper
 - Masking tape
 - Paper towel / alcohol or Iso



- Remove all hardware/stomp pad
- Clean very well with ISO/alcohol
- Remove nicks and ruff edges with scraper blade



- Do a dry trial run making sure o of the accuracy of your placement
- Tape right in the middle to hold the skin down



- Center hinging helps with install because your now only dealing with half the skin at one time, this make application much easier



- Peel back the backing of the skin of only one side ONLY!



- Cut the backing paper off of the skin where the hinge starts.



- Using the squeegee (supplied) start firmly laying your skin down.
- Use a middle up, middle down technique this helps to ensure your left with minimal or no air under your skin.



- Using your Exacto blade trim any excess material from all edges of the board
- If worried use a hair dryer or a heat gun to help seal all the edges
- Re-attach all your hardware and stomp pad

**SKINNED AND READY
TO RIDE IN STYLE!**

